




FRANCE DESIGNED

HUB

Playpen

USER MANUAL




www.jikelbaby.com

IMPORTANT


Retain for Future Reference & Read Carefully






7. Place the mattress in the playpen with the padded side up. Insert the four velcro tabs through the slots in the base of the playpen.


The Usage Of Second Layer



1. Install the Bassinet in the inside of the playpen with all the zippers and then stick on velcro.






2. support tubes into the sleeve provided on the bottom of bassinet and connect them together.



3. Then place the mattress inside the bassinet.



Changing table

Accessories



1. Take out all the accessories of changing table. Let the two long end bars through the changing table as picture.


2. Let the four webbing through the plastic hole. Repeat the same procedure for the other side.



3. Put the changing table to the top rails and make it correctly locked in position. When completely lock in position you will hear a click sound.


4. Put the rotating plastic into the holes of corner as picture 1. The changing table can be hang at the side of bed as picture 2. When not in use.

Sleeping chair




①

1. open the sleeping chair



②




③

2. please pay attention to move the support tube in the right position.


3. please put the plastic holder on the handrail.

Toy gym Assembly



①


1. Assemble all toy gym parts together



②


2. Attach the plastic clips to either side of the playpen as shown.

Storage




Put the storage's two plastic hooks fix to the handrail of bed

To Fold



1. Firstly, remove all the accessories, take the mattress out of the bassinet. Secondly, rotate the plastic lock with 90 degree anticlockwise. Then pull the plastic lock on the bottom base up to loosen the structure. Finally, hold the plastic lock up, then push downward the side rails, do the same for four sides.



2. Draw together all four corners of the playpen. Then insert the second layer inside the playpen and place the other accessories. - Fasten the 3 velcro straps that are around the mattress, and then place inside the travel bag.

WARNING!

If the top rails do not release, ensure that the base is raised fully and lift the rails slightly before pressing the release button.

WARNING!

READ THESE INSTRUCTIONS CAREFULLY BEFORE USE AND KEEP THEM FOR FUTURE REFERENCE. FAILURE TO FOLLOW THESE INSTRUCTIONS MAY JEOPARDIZE THE SAFETY OF YOUR CHILD.

YOUR CHILD'S SAFETY IS YOUR RESPONSIBILITY. CAUTION!

NEVER LEAVE THE CHILD UNATTENDED: IT MAY BE DANGEROUS. PAY UTMOST CARE WHEN USING THE PRODUCT.

- *Be aware of risks related to open fire and other sources of strong heat radiation such as electric or gas radiators etc. placed in the vicinity of bed.*
- *Never use the bed in case any of its parts is broken, torn or lacks; use only components approved by the bed's manufacturer.*
- *Never leave inside the bed or close to it, things that may help the child to get out of the bed or causing the risk of strangulation, such as curtain or window blind cord etc.*
- *Do not use the cot without the base.*

CAUTION

1. *Long-term exposure to direct sunlight may cause fading of fabrics. In such cases, any complaints will not be accepted.*
2. *The Company reserves itself the right to modify the bed structure without the obligation to inform the customers about it.*
3. *Customers will be charged for any repairs necessary because of careless use.*



Never leave your child unattended!

1. The bed is ready to use only when the locking mechanisms are put in operation - always check before you put your child inside that the security elements are locked.
2. Leaving your child unattended check if there is no possibility to get out of bed, for instance through an open side part.
3. When you use other mattress than the original one, make sure that the gap between mattress and bed is smaller than 30mm and that the mattress thickness leaves a space inside (measured from the upper surface of the mattress to the bed frame edge) at least 200 mm on the upper level.
4. We strongly recommend that all assembly fittings should always be tightened properly and that fittings should be checked regularly and retightened as necessary.
5. In order to prevent injuries stop using the bed if your child is able to climb and get out of the bed.
6. Maximum load of the bed is 15 kg.
7. The product is intended for one child only.
8. Periodically check technical condition of your product.
9. During folding and unfolding protect your fingers
10. The base should always be used in the lowest position as soon as the baby is old enough to sit up.
11. To use the lowest level of mattress, disassembly the second level with all supports.
12. Always remember to lock the wheels!

Cleaning

1. All plastic parts may be cleaned using wet, soft cloth. Do not use any aggressive cleaning agents.
2. Metal parts shall only be cleaned using dry cloth.
3. Both the upholstery parts and the mattress may be cleaned using wet, soft cloth using mild washing agents. Do not use any aggressive cleaning agents. Do not whirl and tumble dry!



Handwash in cold water.



Do not bleach.



Do not tumble dry.




Do not iron.




Do not dry clean.

Dry the mattress completely before using or storing it.


To Unfold




1. Open the bag and take all the parts out.




2. Unfasten the 3 velcro straps that are around the mattress.




3. Place the playpen in the vertical position and open the touch fasteners to remove the mattress.



4. Grasp the playpen at the short sides and unfold the playpen.



5. Draw upward the four side rails separately, starting with the short sides first and lift the middle joint up to completely lock in position. When completely lock in position you will hear a click sound.



6. Make sure that all 4 sides of the playpen are correctly locked in position then push down the base pressing the centre.

WARNING!
Don't reverse the above steps. It won't be possible to make the 4 rails locked in position if the centre of the base is down.